

NCDXF/IARU Beacon Monitor KT-003

A useful tool for monitoring HF propagation conditions around the world
 Compact design 140x90 mm, stationary/battery operation of the device
 Synchronized with a time reference from GPS module (worldwide coverage)

Features

- Useful tool for quick HF propagation condition check
- Synchronized with the built-in GPS receiver
- SYNC LED to monitor synchronization status
- CTRL key to change the actual band
- EEPROM memory store the last selected band
- External DC_IN connector (2.1/5.5 type)
- Reverse polarity protection
- Input voltage range: 9.0-16.0 VDC
- Optional battery operation: 3 x AAA (dedicated holes for the battery holder)
- Current consumption: 70 mA @ 9.0 V
- All components are THT type for easy assembly

Mechanical Characteristics

- Metalized front panel with LEDs and CTRL button
- Dimensions: 140 x 90 x 25 mm
- Two-layer PCB (with soldermask and description layer)
- Wooden box available (sold separately)

Application

- Useful tool for easy HF propagation monitoring
- Part of the radio shack

The International Beacon Project

The International Beacon Project (IBP) is a worldwide network of radio propagation beacons. It consists of 18 continuous wave (CW) beacons operating on five designated frequencies in the high frequency band. The IBP beacons provide a means of assessing the prevailing ionospheric signal propagation characteristics to both amateur and commercial high frequency radio users. The project is coordinated by the Northern California DX Foundation (NCDXF) and the International Amateur Radio Union (IARU).

How data is transmitted?

- The beacons transmit on 5 frequencies: 14.100, 18.110, 21.150, 24.930, 28.200 MHz in a 3 minute cycle so that no two beacons transmit at the same time on the same frequency.
- Each beacon transmits once on each band once every three minutes, 24 hours a day.
- A transmission consists of the callsign of the beacon sent at 22 words per minute followed by four one-second dashes.
- The callsign and the first dash are sent at 100 watts. The remaining dashes are sent at 10 watts, 1 watt and 100 milliwatts.
- At the end of each 10 second transmission, the beacon steps to the next higher band and the next beacon in the sequence begins transmitting.

Absolute Maximum Ratings

Maximum Input Voltage:	16.0 VDC
Current consumption @ 9 Vin DC	70.0 mA
Operating Temperature Range:	+5°C to +45°C
Lead Temperature (Soldering 10 sec):	+300°C




FIGURE 1. Assembled NCDXF/IARU Beacon Monitor KT-003

Operation Principle

After the power is turned on the Monitor goes to its Initial State while searching for the GPS timestamp. In this state, all red LEDs are off.

If the complete GPS data frame is received correctly, the system will automatically synchronize with the received time, indicating the currently active beacon on the world map with one of the 18 red LEDs on a given frequency band.

If for some reason the GPS module does not receive fresh data, the system switches to an internal timing state (#3 or #4). For the first 6 hours, the system will remain in state #3. If the last tag was received longer than 6 hours, the system indicates this by switching to state #4.*

Table 1. Possible operating states of the NCDXF/IARU Beacon Monitor

No	State name	LED Sync flashing sequence
1	Initial State	X _____ X _____ X (. . .)
2	In the constant synchronization with GPS signal	XXXXXXXXXXXXXXXXXXXXXXXXX (. . .)
3	Synchronized but actually lost GPS signal	XXXXXXXXXX_XXXXXXXXXX_X (. . .)
4	Synchronized but lost GPS signal longer than 6 hours	XXXXXX _____ XXXXXX _____ X (. . .)

X – LED on, _ – LED off

*) Please note that KT-003 is not equipped with a specialized RTC (Real Time Clock). This can result in a time deviation greater than a second after a few hours. This condition will be indicated as state #4.

Schematic Diagram




FIGURE 2. NCDXF/IARU Beacon Monitor (KT-003) schematic diagram

Circuit Description

The main part of the circuit is the AVR microcontroller (ATmega8A) which gather data from the GPS module (TX line), process data and control all LEDs.

All components are supplied from 3.0 V thanks to LDO voltage regulator (LP2950). In the standard operation the input voltage has to be connected to J1 connector. Accepted input voltage range is 8.5 – 16 V.

Use JP3 connector to solder cables from battery holder (3x AAA). Pay attention to the polarization! Both inputs are protected against reverse polarity.

The JP1 connector allows to program the ATmega8A with a new firmware if available. It uses 2x3 pin ISP header and 3.3 V logic only (5.0 V will damage GPS module!). Newer versions of the firmware will be made available free of charge or sold as a programmed chip. The KT-003 source code is not public.

Mechanical Details

Board dimensions: 140 x 90 x 25 mm (measured with assembled PCBs, front panel, battery pack)
PCB specification: FR 4, 35 um layers, HAL, two-layer, 1.6 mm

On the right side are localised:
- DC input connector (on the right top)
- On/Off Power switch (below)

Using the Beacon Monitor

For proper operation, the GPS module requires the reception of signals from satellites. Modern GPS modules, thanks to high sensitivity, allow you to work even from closed rooms, if they are placed close to the window. However, the level of background EMI noise also matters here. Note that a regular PC and display can generate enough interference to drown out GPS reception within 1 meter.

If you expect that the KT-003 Beacon Monitor will not be placed right next to the window, two solutions are available:

- turn on the KT-003 module and place it next to the window; when it synchronizes, you can move it back to any place; thanks to built-in RTC it can work for many hours with very good synchronization without being in direct range of GPS satellites,
- if stationary operation of the KT-003 module outside the window range is required, then the GPS module should be mounted separately using a 3-wire cable (not included in the kit). Pin 2 on the GPS module (RX line) is not used in this device.

The last selected band setting is saved to EEPROM memory. If you turn on the power again, the system will automatically start from the previously selected BAND.

Assembly Instructions

► **Attention! Electrostatic sensitive components!**
Observe precautions for handling.



Required tools for assembly and startup

- ☐ soldering iron, ☐ tin and flux, ☐ tweezers, ☐ side cutters,
- ☐ digital multimeter, ☐ screwdriver PH1

Recommended assembly order

- ☐ solder diodes: D1 and D2 (1N5148) Watch the polarity!
- ☐ solder choke: L1 (100 uH)
- ☐ solder resistors: R1, R2, R3 (all 2k2)
- ☐ solder resistors: R4, R5, R6, R7, R8 (all 330R)
- ☐ solder resistor: R9 (1k5)
- ☐ solder resistors: R10, R11 (10k)
- ☐ solder resistor: R12 (47R)
- ☐ solder electrolytic capacitors: C1, C4 (100 uF/25 V)
- Pay attention to the polarity of these capacitors! Longer pin is positive.
- ☐ solder ceramic capacitors: C7 and C8 (both 22 pF)
- ☐ solder ceramic capacitors: C2, C3, C5, C9 (all 100 nF)
- ☐ solder crystal oscillator Q1 (8 MHz)
- ☐ solder voltage regulator IC2 (LP2950L-3.0)
- ☐ solder DC input connector: J1 (2.1/5.5 type)
- ☐ solder CTRL switch: S1 (microswitch)
- ☐ solder on/off switch: S2 (two-position sliding switch)
- ☐ solder 28-pin socket into IC1 pad

► At this point all LEDs have to be carefully and precisely soldered. If the diodes are not perfectly straight, it will be not possible to mount the front panel later!

►► A proven, convenient method for soldering all the LED diodes is to insert all the diodes into a PCB board and mount a front panel.

►►► If you make sure that all the diodes are properly seated in the holes, have the correct position and polarity, you can solder them.

►►►► Before you solder any LED diode please check twice where is anode and cathode leg. The cathode (shorter leg) has to be soldered into a rectangle pad on the PCB.

►►►►► Before you solder any LED diode put each diode's leg pair into a plastic spacer to easily get the same height!

- ☐ solder yellow diode: LD24 + plastic spacer
- ☐ solder green diodes: LD19, LD20, LD21, LD22, LD23 (5 pcs) + plastic spacers
- ☐ solder red diodes: LD1...LD18 (18 pcs) + plastic spacers

The next steps concern the GPS receiver:

- ☐ solder GPS antenna first to GPS board as shown in Fig. 5
- First cover the antenna shield with tin and then solder the antenna to the board. Failure to follow this procedure will result in desoldering of the SMT components on the board!
- ☐ carefully connect GPS antenna connector to the board
- ☐ solder 4-pin header into GPS module on the TOP side as shown in Fig. 6
- ☐ place the plastic screw (the screw head should be on the TOP side of the main PCB) and screw the two plastic nuts on the back on each screw
- ☐ put the GPS module into main board and out two nuts
- ☐ solder all four pins to the main board (Fig.6)
- ☐ put microcontroller into socket: IC1 (ATmega8A)
- Note where pin 1 is located on the IC1 footprint!

Note that the ISP connector: JP2 (3x2) should not be installed.

Final assembly step

- ☐ put four M4x10 screws via four holes on the corners of the PCB and then screw it using four metal pins (M3x15 mm)
- ☐ carefully place the front panel and ensure that all installed LEDs and switch fit into the designated holes
- It is possible that some LEDs will require slight soldering adjustments to correct their position!
- ☐ screw the front panel to the back module using four black screws (M3x10)




FIGURE 3. Pin designations




FIGURE 4. Assembled KT-003 board




FIGURE 5. Installing the GPS module




FIGURE 6. Detailed view of GPS soldered pin

If operation with 3 x AAA battery is required install a battery holder (not attached to the kit) on the back side and solder cables to port JP3. Pay attention to the polarity!




FIGURE 7. KT-003 PCB description layer




FIGURE 8. KT-003 front panel layout

Startup Procedure

1. Use the laboratory power supply with current limitation. Start with 0 V DC and set current limiter to 80 mA. Then slowly increase the output voltage and monitor current draw. Expected current draw is 60-80 mA at 9.0 VDC.
2. If you turn on the power while holding down the CTRL button, all the LEDs will light up at once (they are multiplexed, so they do not provide full brightness). This mode allows you to effectively check the polarity and soldering of each LED at once.
3. Each time the power is turned on, the red LEDs start-up sequence begins. After that the default band (14.100) is activated what is indicated by green LED. Click CTRL button to switch to the next band.
4. SYNC diode will blink immediately indicating no data received yet (state #1, as described in Table 1). After synchronizing with GPS signal, the LED will light up permanently.

Components List

Table 2. Components list

No.	DESIGNATOR	DESCRIPTION	QTY	PART NUMBER	VALUE
1	R1, R2, R3	2k2/0.25W THT resistor	3		
2	R4, R5, R6, R7, R8	330R/0.25W THT resistor	5		
3	R9	1k5/0.25W THT resistor	1		
4	R10, R11	10k/0.25W THT resistor	2		
5	R12	47R/1,0W THT resistor	1		
6	C1, C4	100u/25V THT electrolytic	2		
7	C2, C3, C5, C9	100n/35V THT ceramic	4		
8	C7, C8	22pF/16V THT ceramic	2		
9	D1, D2	Schottky diode THT	2	1N5818	
10	L1	Choke THT	1		100uH
11	Q1	8 MHz quartz crystal oscillator THT low-profile	1		
12	LD1...LD18	LED 2 mm red THT	18		
13	LD19...LD23	LED 2 mm green THT	5		
14	LD24	LED 2 mm yellow THT	1		
15		Spacer sleeve for LED	24		
16	IC1	ATmega8A DIP-28 THT (already programmed)	1	ATmega8A	
17	IC2	Voltage regulator TO-92 THT	1	LP2950L-3.0	
18	JP1	GPS module	1	GY-GPS6MV2	
19	JP2, JP3	--- not installed ---	-		
20	J1	2,1x5,5 DC connector, angle version, THT	1		
21	S1	Switch momentary (Tact-switch)	1		
22	S2	Switch 2-position (sliding switch)	1		
23	JP1	Goldpin 4x1 (for GPS module)	1		
24		Metal pins M3x15 female-female	4		
25		Black M3x10 screws	4		
26		M3x8 screws	4		
27		M3x10 poliamid screws (for GPS module assembly)	2		
28		Poliamid nuts M3	6		
29		Metalised plastic front panel for KT-003	1		
30		Printed circuit boards (140x90 mm)	1		
31		28-pin DIP socket	1		

Ordering Information

Table 3. Ordering information

Description	Version	Ordering Code	QTY
Microcontroller ATmega8A DIP28 (programmed with the latest firmware)	MCU	KT-003U	1
Printed Circuit Board only	PCB	KT-003P	1
Kit for self assembly	Kit	KT-003K	1
Assembled module	Assembled	KT-003A	1
Assembled module KT-003 in a wooden housing	Assembled	KT-003AB	1

KRAIT Technologies
29/166 Stefana Batorego Street
02-591 Warsaw
Poland
EUROPE

www.krait-technologies.com
 ©2023-2024 KRAIT Technologies. All rights reserved.

An information furnished by KRAIT Technologies is believed to be accurate and reliable. However, no responsibility is assumed by KRAIT Technologies for its use, nor for any infringements of patents or other rights of third parties that may result from its use. Specifications subject to change without notice.

Typographical and other errors do not justify any claim for damages.
 Trademarks and registered trademarks are the property of their respective owners.



Made in POLAND



Appendix A

Table 4. Detailed location of NCDXF/IARU beacons

Slot	DX Entity	Callsign	Location	Latitude	Longitude
1	United Nations	4U1UN	New York City	40° 45' N	73° 58' W
2	Canada	VE8AT	Eureka, Nunavut	79° 59' N	85° 57' W
3	United States	W6WX	Mt. Umunhum	37° 09' N	121° 54' W
4	Hawaii	KH6RS	Laie	21° 38' N	157° 55' W
5	New Zealand	ZL6B	Masterton	41° 03' S	175° 36' E
6	Australia	VK6RBP	Rolystone	32° 06' S	116° 03' E
7	Japan	JA2IGY	Mt. Asama	34° 27' N	136° 47' E
8	Russia	RR9O	Novosibirsk	54° 59' N	82° 54' E
9	Hong Kong	VR2B	Hong Kong	22° 16' N	114° 09' E
10	Sri Lanka	4S7B	Colombo	6° 54' N	79° 52' E
11	South Africa	ZS6DN	Pretoria	25° 54' S	28° 16' E
12	Kenya	5Z4B	Kiambu	1° 1' S	37° 3' E
13	Israel	4X6TU	Tel Aviv	32° 03' N	34° 46' E
14	Finland	OH2B	Karkkila	60° 32' N	24° 06' E
15	Madeira	CS3B	Santo da Serra	32° 43' N	16° 48' W
16	Argentina	LU4AA	Buenos Aires	34° 37' S	58° 21' W
17	Peru	OA4B	Lima	12° 04' S	76° 57' W
18	Venezuela	YV5B	Caracas	10° 25' N	66° 51' W

Appendix B

Table 5. Detailed NCDXF/IARU beacon broadcasting time slots

Callsign	Location	14.100	18.110	21.150	24.930	28.200	Operator
4U1UN	United Nations	00:00	00:10	00:20	00:30	00:40	UNRC
VE8AT	Canada	00:10	00:20	00:30	00:40	00:50	RAC/NARC
W6WX	United States	00:20	00:30	00:40	00:50	01:00	NCDXF
KH6RS	Hawaii	00:30	00:40	00:50	01:00	01:10	NOARG/HARC
ZL6B	New Zealand	00:40	00:50	01:00	01:10	01:20	NZART
VK6RBP	Australia	00:50	01:00	01:10	01:20	01:30	WIA
JA2IGY	Japan	01:00	01:10	01:20	01:30	01:40	JARL
RR9O	Russia	01:10	01:20	01:30	01:40	01:50	SRR
VR2B	Hong Kong	01:20	01:30	01:40	01:50	02:00	CRSA/HARTS
4S7B	Sri Lanka	01:30	01:40	01:50	02:00	02:10	RSSL
ZS6DN	South Africa	01:40	01:50	02:00	02:10	02:20	ZS6DN
5Z4B	Kenya	01:50	02:00	02:10	02:20	02:30	ARSK
4X6TU	Israel	02:00	02:10	02:20	02:30	02:40	IARC
OH2B	Finland	02:10	02:20	02:30	02:40	02:50	SRAL
CS3B	Madeira	02:20	02:30	02:40	02:50	00:00	ARRM
LU4AA	Argentina	02:30	02:40	02:50	00:00	00:10	RCA
OA4B	Peru	02:40	02:50	00:00	00:10	00:20	RCP
YV5B	Venezuela	02:50	00:00	00:10	00:20	00:30	RCV